



American Flooring Accessories

Rubber Cove Wall Base Maintenance

- Rubber Wall Base can be routinely cleaned by wiping with a soft cloth dampened with warm water.
- **WARNING:** Coarse cleaning materials and/or harsh cleaning agents may damage the surface of the base. Always test maintenance procedure in an inconspicuous location